



Our new and improved troubleshooting section was carefully constructed to put the power to repair your machine in your hands. As you can tell, we have put a great deal of time and effort into the process. All of this can save you the cost of a service call which is approaching \$150 in many markets and in many cases, we can save you the cost of parts since many parts are sold from factories unnecessarily (many parts cost over \$100 alone). With all of this said, if our troubleshooting tips help you out, please donate to keep this info on the web and so we can continue to add to it for your future use. As we get the funds, we will start to post video helps too. If this info helps you, please click on the donate button and donate to help us expand and maintain our troubleshooting help. Donations are NOT tax deductible.

ICON CALIBRATION INSTRUCTIONS- INCLINE

- 1) Press the Stop and the Speed Up keys down while inserting the safety key. If this doesn't work, click on the help topic entitled "Alternate Calibration Codes" for key sequence instructions to enter calibration.
- 2) Press the Stop key one time. The Time window should read EP: 2P. Some newer models may also say FP, Pass, or the like. This means that it passes the EPROM test.
- 3) Press either incline key and the incline will calibrate automatically.
- 4) **THIS IS A VERY IMPORTANT STEP BECAUSE YOU WILL GET AN ERROR MESSAGE IF THIS STEP IS SKIPPED.** After completing calibration of incline, press the Stop key and then remove the safety key.
- 5) If you have any questions about these instructions or if you need further assistance, please contact us online at www.treadmilldoctor.com, call any weekday from 8 am to 5 pm, or email us at doc@treadmilldoctor.com.

Copyright © 2008 by TreadmillDoctor.com, Inc.

All illustrations, photographs, and scanned images, and text are the property of TreadmillDoctor.com, Inc. and may not be reused, retransmitted, copied, given, sold, or bartered to any third party. The recipient of this property is authorized to use it only in the manner expressly indicated by a staff member of TreadmillDoctor.com, Inc. All rights reserved.